


FAMES In Coconut Oil by GC/MS on Zebron ZB-FAME**Column:** Zebron ZB-FAME, GC Cap. Column 30m x 0.25mm x 0.2µm , Ea**Phase:****Dimensions:** 30 meters x 0.25 mm x 0.2 µm**Order No:** 7HG-G033-10**Oven Profile:** 100 °C for 2 min to 214 °C @ 3 °C/min**Carrier Gas:** Constant Flow Helium, 1 mL/min**Injection:** Split 50:1 1 µL @ 240°C**Detection:** Mass Spectrometer (MS) (250°C)

Analyst Note: Recommended Accessories:
Recommended Liner: Zebron PLUS Single Taper Z-Liner, 4 mm ID
Liner Part No.: AG2-0A13-05 (for Agilent systems)
Inlet Seal: AG0-8620 (Gold Plated Easy Seal)
Septum: AG0-4696 (PhenoRed-400)

Sample Preparation:

1. Weigh out 25 mg of oil into a 5 mL screw cap glass vial
2. Add 2 mL of BF₃-methanol to sample vial
3. Heat vial at 60 °C for 15 minutes with periodic vortexing
4. Remove from heat and allow to attain room temperature
5. Add 1 mL water followed by 1 mL hexane
6. Vortex for 1 minute
7. Remove upper organic layer
8. Dry hexane layer over anhydrous sodium sulfate
9. Transfer to autosampler vial and inject on GC

**Products used in this application:****ANALYTES:**

- 1 C6:0
- 2 C8:0
- 3 C10:0
- 4 C12:0
- 5 C14:0
- 6 C16:0
- 7 C18:0
- 8 C18:1 cis 9
- 9 C18:2 cis 9,12

